# How to apply your Silver Fox Thermal Labels



# Storage

Storage Instructions:	Store between 50° F (10° C) and 77° F (25° C)
Shelf Life:	2 Years
Conditions:	Keep in dark conditions
Humidity Resistance:	35% to 65% RH

# **Printing**

Labelling information to be printed should be prepared using the Silver Fox Labacus Innovator labelling software. The labels should be printed using the Silver Fox DTP-1/300 thermal printer. Follow the instructions in the printer manual and/or help file for printer settings

# Preparation

The surface of the product to be labelled should be clean, dry, should have no grease and be dust free. The product may be cleaned with an industrial cleaning solution or Isopropyl Alcohol (check product instructions before doing this). Wipe dry with a clean lint-free cloth. It is recommended that the operative applying the labels should wash and dry their hands before applying the product to remove and dirt or grease that may be present.

#### **Application**

### **Adhesive Labels**

Remove the adhesive label from the backing sheet then carefully apply to the surface of the product.

#### Tie-on Labels

Carefully tear the label off the strip then apply to the product using either standard grade nylon cable ties or stainless steel cable ties.

## Heatshrink/Non-Shrink

Carefully cut each label from the strip at the cut marks with scissors then slide on to the cable. In the case of heatshrink a standard heat gun can be used at a low-mid range heat setting.

## Support

If you require any assistance then please contact our Support Team:

Email: support@silverfox.co.uk
Website: http://support.silverfox.co.uk
Tel: +44 (0) 1707 37 37 27

Hours: Mon-Thurs 08:45 – 17:30 GMT

Friday 08:45 - 16:30 GMT



All Enquiries:

tel: +44 (0)1744 762 929
email: sales@etechcomponents.com
web: www.etechcomponents.com

Copyright © 2016 Silver Fox Limited

0